

# ESI Rust and Stain Remover

ESI Rust and Stain Remover removes rust and stains from metal surfaces and requires no rinsing once the surface is dry.



## SOAKING DIRECTIONS:

1. Add one part of concentrate to ten (10) parts water.
2. Soak for 15 minutes or until metal surface is clean. Periodic agitation will help speed up the process.
3. Remove parts and allow to dry. No need to rinse.

## BRUSH APPLICATION:

1. Add one part of concentrate to ten (10) parts water.
2. Apply liberally to the metal surface, brush, and let stand for 10 minutes.
3. Brush again and allow to dry. No need to rinse.

## PACKAGING:

- 4x1 Gallon

**ENZYME SOLUTIONS®**  
INCORPORATED

2105 Forrest Park Drive  
Garrett, IN 46738  
800-523-1323 Phone • 260.497.0512 Fax  
[www.enzymesolutions.com](http://www.enzymesolutions.com)